

How to change the battery&LED module-DE27211

| No. | Step | Photo | Tool |
|-----|--|--|-------------|
| 1 | Remove the two screws that fix the transparent cover and take out the transparent cover |  | Screwdriver |
| 2 | Remove the two screws that fix the LED module |  | Screwdriver |
| 3 | Unplug the two wires connecting the light source, remove the light source, and replace the required light source |  | |
| 4 | Remove the two screws that fix the battery plate |  | |
| 5 | Remove the battery clip and unplug the battery, replacing the required battery |  | |